



art. 5903

LISTA RICAMBI
SPARE-PARTS LIST

POS.	CODICE	DESCRIZIONE	DESCRIPTION	PCS	POS.	CODICE	DESCRIZIONE	DESCRIPTION	PCS
01	03 00 26	Rubinetto	Cock	4	13	04 00 13	Pennello	Brush	4
02	03 10 04	Rubinetto	Cock	1	14	04 00 14	Fascetta	Fastening	3
03	03 00 85	Raccordo	Connection	2	15	04 00 15	Vasca	Bench	1
04	04 00 04	Nipples	Adapter	2	16	04 00 16	Griglia	Grid	1
05	04 01 05	Coperchio	Lid	1	16A	04 01 16A	Raccordo	Adapter	1
06	04 01 06	Raccordo	Adapter	1	17	04 01 17	Raccordo	Adapter	1
07	03 00 40	Ghiera	Ring nut	1	18	04 00 18	Tubo	Hose	2
08	04 01 08	Spinotto	Pointer	1	19	03 01 64	Ruota piroettante	Swivelling wheel	2
08A	04 01 08A	Supporto	Bracket	2	20	04 01 20	Boccola	Bush	1
09	04 01 09	Serbatoio	Tank	1	21	72 00	Riduttore di pressione	Press reducer	1
10	04 01 10	Fascetta sup.	Upper fasten	2	22	03 01 75	Ruota fissa	Fixed wheel	2
11	04 C1 11	Fascetta inf.	Under fasten	2	23	04 01 23	Tubo aspirazione	Suction pipe	1
12A	04 01 12A	Corpo	Body	1	24	04 01 24	Tubo livello	Level pipe	1
13A	03 00 27	Raccordo "V"	"V" connection	1	25	04 00 25	Portagomma	End-hose	1